cron

03. Side Cover Assembly


Written By: Paul Cronje



INTRODUCTION


This document was generated on 2021-12-25 12:58:07 AM (MST).

Step 1 — Parts required




- Side covers: Small (2 Pcs), Medium (4 Pcs), Large (6 Pcs)
- 20x40 Aluminium Profiles (2 Pcs)
- M5x8 Button Head screw: Small (12 Pcs), Medium (24 Pcs), Large (36 Pcs)
- M5 Slide T-Nut: Small (12 Pcs),
 Medium (24 Pcs), Large (36 Pcs)

Step 2 — Tools required



- 3mm Allen Key
- Pratley Pratlock

Step 3 — Slide T-nuts into profiles



- Slide the M5 T-Nuts into the side of the 20x40 V-Slot profile
- The following quantity T-nuts is required for each machine size:


Small: 3 T-Nuts per slot

Medium: 6 T-Nuts per slot

Large: 9 T-Nuts per slot

03. Side Cover Assembly Guide ID: 3 - Draft: 2019-03-25

Step 4 — Mount the side covers





- Use the M5x8 button head screws (6 Pcs per side cover) and mount it to the V-Slot Profile while adding Pratley Pratlock to the screws
- The side covers should not extend further than the V-Slot profile at the ends and should be against each other in the middle
- Tighten the screws with the 3mm Allen Key when the covers are in place