



cron

06. Connect laser cables

Written By: Paul Cronje



Step 1 — Parts required





- 12V E-Stop cable

Step 2 — Tools required





- Phillips Screw driver
- Small Flat screw driver

Step 3 — Connect to E-Stop



- Connect the 12V E-Stop cable to the orange side (normally Closed) on the E-Stop as shown

Step 4 — Connect to 12V Power supply



- Connect the other end of the cable to one of the V+ ports on the 12V power supply as shown
- Connect the black ground cable from the laser to one of the GND terminals on the 12V power supply.